



289 Wagaraw Road, Hawthorne NJ 07506
njsteel@njsteelbaron.com
SteelBaron.com
973-949-4140

15N20 | Heat Treating

About 15N20 **2**

Alloy Chemistry % 2

About 15N20 **3**

Blade Steel Comparagraph 3

Heat Treating **4**

Normalization 4

Hardening 4

Heat Treating **5**

Tempering 5

Heat Treating Disclaimer **6**



289 Wagaraw Road, Hawthorne NJ 07506
njsteel@njsteelbaron.com
SteelBaron.com
973-949-4140

15N20 | Heat Treating


About 15N20

15N20 is a high nickel alloy most commonly used with 1084 or 1095 to create pattern welded or "Damascus" steel.

We carry a variety of different thicknesses up to 1/8" and have found that even 15N20 on its own makes great knife steel. In other industries, it is used for saw blades.

Very tough, similar to AISI L6 tool steel, except for the missing Chrome. 15N20 is used either as a blade material on its own, or mixed with other steel in pattern welded damascus. E.g. 15N20/AISI 1095 steel or 15N20/AISI 1084 steel are quite popular. Nickel in 15N20 provided good contrast. Easy to sharpen, takes fine edge, but not so much in the edge holding department, toughness is its main benefit. Although, western custom knife makers use it in kitchen knives at higher hardness. Also used to make swords.

Alloy Chemistry %






289 Wagaraw Road, Hawthorne NJ 07506
njsteel@njsteelbaron.com
SteelBaron.com
973-949-4140





15N20 | Heat Treating

About 15N20

Blade Steel Comparagraph





 289 Wagaraw Road, Hawthorne NJ 07506
 njsteel@njsteelbaron.com
 SteelBaron.com
 973-949-4140

15N20 | Heat Treating

Heat Treating

Normalization


- Normalization is a process intended to refine grain and stress relieve blades prior to hardening when needed.
- Turco, ATP-641, foil, or similar may be used to reduce surface decarburization and scaling.
- Time at temperature suggested for varying thicknesses. Once knife has cooled to black and magnetic, it can be cycled again--be careful handling hot blades.



1st Cycle	2nd Cycle	3rd Cycle
1,650°F / 898°C Hold 10-15 minutes	1,500°F / 815°C Hold 10-15 minutes	1,350°F / 732°C Hold 10-15 minutes

Hardening

- ATP-641, Turco, or similar high temperature anti-scale/decarburization coatings can be used to reduce scale or surface decarburization.
- Data is representative of controlled heat treating equipment (e.g. oven, salts, etc.) temperatures and industrial standard quenchant.
- Suggested quench oil: Parks 50--expected as quenched hardness may be lower if a slower quench oil or non-industrial quench medium is used.
- **Austenizing soak time varies 5 to 15 minutes based on heat treating equipment and cross section--soak times are reduced to minimum for people heat treating in a forge--forge heat treating without PID temperature control limits accurate means of maintaining temperature. If using calibrated, proper industrial equipment for heat treating, use the supplied extended soak times based on over all steel thickness.**
- **Do not put blades in oven when cold, insert at or just below austenizing temperature--temperature variances is for difference in stock thicknesses and a window of margin for error.**



Austenizing Temperature	Expected RC (as quenched)
1,450-1,480°F / 788-804°C Soak 5-15 minutes	64-65RC



289 Wagaraw Road, Hawthorne NJ 07506
njsteel@njsteelbaron.com
SteelBaron.com
973-949-4140

15N20 | Heat Treating

Heat Treating

Tempering

- Once blade is quenched and near ambient temperature, blades should be tempered accordingly, the times suggested are to ensure even, consistent temperature.
- Figures supplied are as representative of industrial standards.
- **If using a small toaster oven or household kitchen oven for tempering, using a blade holding rack made from kiln furniture, a roasting tray lined with fine sand, or similar large object will help retain thermal mass to reduce wide swinging temperatures as the device fluctuates trying to maintain temperature.**
- **Note: Final hardness values vary based on initial as-quenched hardness and percentage of conversion to Martensite. Only reliable testing methods, e.g. calibrated Rockwell hardness tester, can provide actual hardness values--hardness calibrated files and chisels are relative testing methods and inaccurate for true hardness value reading.**
- Temper twice for 2hrs.



Temperature:	Hardness (2 hour x2 guideline):
300°F / 149°C	65
350°F / 177°C	63-64
400°F / 204°C	60-61
450°F / 232°C	57-58
500°F / 260°C	55-56
550°F / 288°C	53-54
600°F / 316°C	52-53
650°F / 343°C	50

- The included Heat Treat Schedule on this page is formulated based upon Industry standards and data from ASM International, Crucible and other foundry spec sheets, and Kevin Cashen (independent researcher, ferroalloy metallurgist, and bladesmith of Matherton Forge).





📍 289 Wagaraw Road, Hawthorne NJ 07506
✉ njsteel@njsteelbaron.com
🌐 SteelBaron.com
📞 973-949-4140

15N20 | Heat Treating

Heat Treating Disclaimer

- Suggested heat treatment are based on the recommended specifications for use in ovens, high temp salts, and similarly, properly calibrated equipment; and in line with proper industrial standards for quenching. Deviation from industry standards for schedules, equipment, quenching mediums; and hardness testing equipment may result in varied results. The supplied information on this page is on a generalized scale with the above mentioned standards and methods, which is why soak times and similar aspects may vary in time length to include a margin for the available heat treating equipment and steel cross section.
- If you are unsure if you have the necessary means to heat treat on-site, we recommend professional heat treating services provided by Peters Heat Treat or Bos Heat treating; or industry specific services by knife material dealers such as TruGrit or Texas Knifemaker's Supply--check with suppliers to see if they offer HT services and ensure they follow industry standards.
- NJSB LLC is not liable or responsible if proper industry heat treating protocols are not applied; particularly and especially if sending to an independent heat treat provider if they do not follow the intended heat treat schedule or standards for that particular steel; or damage they cause while in their possession.

